

Configuring the GPS Adapter Cable

If you swapped Windows disks, recovery disks, or GPS adapter cables, you must assign port number four to the adapter cable to match the cable and Windows system to each other. Use the following steps to solve the issue:

1. Right click on **My Computer** and select **Properties**.
2. Select the **Hardware** tab and click on the **Device Manager** button.
3. Scroll to **COM Ports and LPT** and click on the “+” to expand it.
4. Right click on **Serial Adapter on USB** and select **Properties**.
5. Select the **Port Settings** tab and make sure that the data rate is set to 4800.
6. Click on the **Advanced** button, select **COM 4**, and click **OK**.
7. Click **Yes** in the dialog box, if any, warning you about COM port conflicts.
8. Click **OK** and close the dialog boxes.